


Basic Guide to Your Remote Control

Mode button lets you change the remote to control TV, AUD, DVD, AUX, STB

TV, AUD, DVD, and Aux need to be programmed STB is pre-programmed



STB = Set Top Box
DVR = Digital Video Recorder